

# HYVOX®

## CORDLESS KETTLE



### **USER'S MANUAL**

Model HI-315

*Thank you* for purchasing Hyvox Cordless Kettle, from Hyvox Ingenious Home Collection of products. Please read your user's manual carefully as it provides important information regarding safety, operation and maintenance. Please kindly retain this manual and model number for future reference.

**Ingenious Home Collection**  
*Changing life concepts!*



MAX  
1.5 l

1.0 l

0.5 l

MIN

HYVOX

# *Thank you.*

We appreciate your business. Thank you for purchasing Hyvox Cordless Kettle from the Hyvox Ingenious Home Collection of products.

*Changing Life Concepts!*

# CONTENTS

Cordless Kettle.....	02
Anatomy of the Kettle.....	03
Safety Instructions.....	04
Operating instructions.....	06
Care and Cleaning.....	07
Warranty information.....	08

# **CORDLESS KETTLE HI-315**

**Hyvox brings you another Ingenious Home Collection that will brighten your day with easy boiling water.**

A brush finish stainless steel design electric cordless kettle to give you hot water in style. Hyvox Ingenious Home Collection brings you designer style Cordless Kettle for your creative kitchen. Comes with 1.5L capacity, auto switch off, external water level indicator and overheat safety protection. Live fast life in conceptual style.

## **ADVANTAGEOUS FEATURES**

- 01.** 1.5L capacity stainless steel brush finish
- 02.** 360° rotation electric cordless kettle
- 03.** Includes water filter for straining
- 04.** External water level indicator
- 05.** External light indicator
- 06.** Safety locking lid
- 07.** Automatic and manual boiler switch off
- 08.** Overheat safety protection
- 09.** With concealed heating protection
- 10.** Power 220-240V-50-60Hz / 1500W

# ANATOMY OF CORDLESS KETTLE

Here we explain to you the various parts of the Cordless Kettle.



**1** Lock/Unlock cover

**3** Cover

**5** Indicator lamp

**7** Kettle Handle

**2** Spout

**4** On/Off switch (O/I)

**6** Water level indicator

**8** Base station

# SAFETY INSTRUCTIONS

**To reduce the risk of fire, electric shock, or injury, basic precautions mentioned below should be followed.**

01. Before commissioning this device please read the instruction manual carefully.
02. Please keep these instructions, the guaranty certificate, the sales receipt and, if possible, the carton with the inner packaging!
03. The Device is intended exclusively for private and not for commercial use!
04. Always remove the plug from the socket whenever the device is not in use, when attaching accessory parts, cleaning the device or whenever a disturbance occurs. Switch off the device beforehand. Pull on the plug, not on the cable.
05. In order to protect children from the dangers to electrical appliances, never leave them unsupervised with the device. Consequently, when selecting the location for your device, do so in such a way that children do not have access to the device. Take care to ensure that the cable does not hang down.
06. Test the device and the cable regularly for damage. If there is damage of any kind, the device should not be used.
07. Do not repair the device yourself, but rather consult an authorized expert.

## **SAFETY INSTRUCTIONS cont...**

08. For safety reasons a broken or damaged mains lead may only be replaced by an equivalent lead from the manufacturer, our customer service department or a similarly qualified person.
09. Keep the device and the cable away from heat, direct sunlight, moisture, sharp edges and suchlike.
10. Never use the device unsupervised! Switch off the device whenever you are not using it, even if this is only for a moment.
11. Use only original accessories.
12. Do not use the device outdoors.
13. Under no circumstances must the device be placed in water or other liquid, or come into contact with such. Do not use the device with wet or moist hands.
14. Should the device become moist or wet, remove the mains plug from the socket immediately. Do not reach into the water.
15. Use the device only for the intended purpose.
16. Use only cold water when filling.
17. The water level must be between the MAX and MIN.
18. Switch the machine off before removing it from the base.
19. Always ensure that the lid is tightly closed.
20. The base & exterior of the machine must not become wet.

# OPERATING INSTRUCTIONS

**Please follow the instructions below carefully. They contain important boiling instructions and guidelines.**

01. Before using the kettle for the first time, water should be boiled in it twice without any additives.
02. Place the machine on a flat surface. Fill the kettle with water. Do not overfill! Use the water level indicator.
03. Place the kettle flush on the base.
04. Check whether the electrical voltage that you intend to use is the same as that of the machine. Details are to be found on the label on the base.
05. Switch the machine to position “I”. The control lamp on the water level indicator shows that the water is being boiled.
06. After boiling, the machine switches off automatically.
07. Disconnect the machine from the main electricity supply.
08. Do not press up the lid when pouring.

## CARE & CLEANING

**If servicing is needed, take it to our service centre. Do not try to repair it. There are no user serviceable parts.**

01. Always remove the plug from the main supply before cleaning the machine!
02. The exterior of the machine should be cleaned, if necessary, with a slightly damp cloth without additives.
03. The calcium filter can be removed for cleaning.

# WARRANTY INFORMATION

**This warranty covers only manufacturer defectives for one year, with the exceptions stated below.**

## **What Is Not Covered**

This warranty does not cover any damage caused due to physical abuse of the product by misuse or use other than as intended and described in the instruction manual, or damage caused by failure to properly clean and maintain this product or damages caused by natural disaster or acts of war. The warranty is voided if connected to any voltage or specifications other than prescribed on the product. Also, if the unit is opened for self repair, the warranty will be void for any further repair or problem analysis. The warranty may not be used if the product is served in public places such as lodging house, training centres etc. Warranty does not cover any shipping and handling charges. Hyvox Inc. reserves the right to refuse any warranty claim without any valid reasons.

## **What Will We Do**

Should you detect any malfunction, please return the damaged product along with the purchase receipt with a brief explanation of the problem, either directly to a distributor of Hyvox products near you or to the shop you had purchased from. We will repair any defects in materials or workmanship within one year of purchase. If the defective is found un-repairable within the warranty period, Hyvox with its discretion will replace it for a new unit. However, Hyvox reserves complete rights in decision making in regards to processing the warranty, rejecting any claim without any valid reason or arranging a replacement.

If you have any questions, please feel free to contact our customer service e-mail or our local distributors near you. Please visit [www.hyvox.com](http://www.hyvox.com) to find a local distributor near you.

Send us your valuable suggestions and feedback.  
Login to [www.hyvox.com](http://www.hyvox.com).

You can also find a copy of this document for download and other supportive materials on our website. Thank you once again for purchasing Hyvox Cordless Kettle, your Ingenious Home Collection.

Find more Hyvox Ingenious Home Collection products at

**[www.hyvox.com](http://www.hyvox.com)**

***Changing life concepts!***

**HYVOX<sup>®</sup>**

**Ingenious Home Collection**  
*Changing life concepts!*

Hyvox Inc.  
100 City Centre Dr, RPO 2239,  
Mississauga, Ontario  
Canada L5B 3C7

[info@hyvox.com](mailto:info@hyvox.com)  
[www.hyvox.com](http://www.hyvox.com)

---

'Hyvox' brand name and logo, 'Ingenious Home Collection' and 'Changing life concepts!' are registered trademarks of Hyvox Inc., Ontario, Canada.

Copyright © Hyvox Inc. 2005. E&OE.