

HYVOX® BREAD TOASTER



USER'S MANUAL Model HI-320

Thank you for purchasing Hyvox Bread Toaster, from Hyvox Ingenious Home Collection of products. Please read your user's manual carefully as it provides important information regarding safety, operation and maintenance. Please kindly retain this manual and model number for future reference.

Ingenious Home Collection
Changing life concepts!

YVOX

4
5
6
7



DEFROST



REHEAT



STOP



Thank you.

We appreciate your business. Thank you for purchasing Hyvox Bread Toaster from the Hyvox Ingenious Home Collection of products.

Changing Life Concepts!

CONTENTS

| | |
|-------------------------------|----|
| Bread Toaster..... | 02 |
| Anatomy of Bread Toaster..... | 03 |
| Safety Instructions..... | 04 |
| Warning..... | 06 |
| Operating Instructions..... | 07 |
| Warranty information..... | 08 |

BREAD TOASTER HI-320

Hyvox brings you another Ingenious Home Collection that will brighten your day with easy toasting.

A perfect companion for your breakfast needs. With an electronic timer control, it makes perfect toast. You can make upto 2 slices at a time. Has a detachable crumb collector tray, making it easy to clean. Built with executive contemporary design, it will be a perfect addition to your Ingenious Home Collection.

ADVANTAGEOUS FEATURES

01. Reheat, defrost, cancel button.
02. Detachable crumb collector tray.
03. Outboard bread shelf.
04. Electronic control timer.
05. Auto turn off function.
06. Power 220-240V / 850W.

ANATOMY OF HYVOX BREAD TOASTER

Here we explain to you the various parts of the Bread Toaster.



1 Bread insert

2 Electronic variable browning control

3 Crumb tray

4 Bread release

5 Defrost button

6 Reheat button

7 Stop button

SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, basic precautions mentioned below should be followed.

01. Please read these instructions before operating and retain for future reference.
02. To protect against electrical hazard do not immerse any part of the appliance or cord in water or any other liquid.
03. Close supervision is necessary when the appliance is used near children.
04. Do not leave the appliance unattended when in use.
05. Always use the appliance on a dry, level surface.
06. Do not use this appliance outdoors.
07. Always unplug from the plug socket when not in use and before cleaning.
08. Do not operate the appliance if damaged. After an appliance malfunctions or it has been damaged in any manner, return to an authorized service engineer for repair, because special purpose tools are required.
09. In the interest of safety, regular periodic close checks should be carried out on the supply cord to ensure no damage is evident. Should there be any signs that the cord is damaged in the slightest degree, the entire appliance should be returned to authorized service engineer.
10. Do not let the cord hang over the edge of a table or counter or touch hot surfaces. Allow unit to cool before wrapping cord around base for storage.

SAFETY INSTRUCTIONS cont...

11. Care must be taken not to touch any hot surfaces. Do not store or cover the appliance until it has fully cooled down.
12. Do not place this appliance on or near a hot gas or electric burner, in or where it could touch a heated oven, or a microwave oven.
13. Do not use harsh abrasives, caustic cleaners or oven cleaners when cleaning this appliance.
04. **THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY. DO NOT USE THE APPLIANCE FOR ANYTHING OTHER THAN INTENDED USE.**
15. Do not use the toaster without the slide out crumb tray in place. The crumb tray should be cleaned regularly. Do not allow crumbs to build up in the tray.
16. Do not use this appliance with any foodstuff product containing sugar content or with products containing jam or preserves.

WARNING!

Things you should always keep in mind for a healthy enjoyment of this ingenious unit.

01. Bread may burn. When using this appliance, allow adequate air space above and on all sides for air circulation.
02. Do not allow this appliance to touch curtains, wall coverings, clothing, dish towels or other flammable materials during use.
03. Caution is required on surfaces where heat may cause a problem – an insulated heat pad is recommended.
04. Never attempt to extract jammed toast, muffins, bagels or any other item with a knife or any other object, as contact with live elements may cause electrocution.
05. Allow the appliance to cool down, unplug and carefully remove the bread.
06. To prevent electric shock, disconnect from the mains before removing cover.
07. No user serviceable parts inside. Refer servicing to qualified service personnel.
08. **DO NOT LEAVE TOASTER UNATTENDED WHEN IN USE**

OPERATING INSTRUCTIONS

Please follow the instructions below carefully. They contain important toasting instructions and guidelines.

01. Insert the plug into a suitable main supply socket and turn the power on.
02. Place two slices of bread, muffins or bagels into the bread slots.
03. Select the desired browning setting, from No.1 to No.7 on the browning control knob (No.1 lightest, No.7 – darkest). When using the toast for the first time we suggest you toast on number 3. Different types of bread and personal preference may require a different browning setting.
04. Press the carriage control lever down until it clicks into place. Toasting cycle will automatically commence. Please Note: if the toaster is not plugged in and switched on, the carriage control lever will not click into place.
05. The toaster turns off when the desired toast colour is achieved and automatically pops up the toast. The toasting process can be stopped at any time by pressing the cancel button.
06. **TOASTING FROZEN BREAD** - To toast frozen bread, place the bread into the bread slots and select the desired browning Setting. Press the carriage control lever down until it clicks into place. Then press the Frozen Button.

WARRANTY INFORMATION

This warranty covers only manufacturer defectives for one year, with the exceptions stated below.

What Is Not Covered

This warranty does not cover any damage caused due to physical abuse of the product by misuse or use other than as intended and described in the instruction manual, or damage caused by failure to properly clean and maintain this product or damages caused by natural disaster or acts of war. The warranty is voided if connected to any voltage or specifications other than prescribed on the product. Also, if the unit is opened for self repair, the warranty will be void for any further repair or problem analysis. The warranty may not be used if the product is served in public places such as lodging house, training centres etc. Warranty does not cover any shipping and handling charges. Hyvox Inc. reserves the right to refuse any warranty claim without any valid reasons.

What Will We Do

Should you detect any malfunction, please return the damaged product along with the purchase receipt with a brief explanation of the problem, either directly to a distributor of Hyvox products near you or to the shop you had purchased from. We will repair any defects in materials or workmanship within one year of purchase. If the defective is found un-repairable within the warranty period, Hyvox with its discretion will replace it for a new unit. However, Hyvox reserves complete rights in decision making in regards to processing the warranty, rejecting any claim without any valid reason or arranging a replacement.

If you have any questions, please feel free to contact our customer service e-mail or our local distributors near you. Please visit www.hyvox.com to find a local distributor near you.

Send us your valuable suggestions and feedback.
Login to www.hyvox.com.

You can also find a copy of this document for download and other supportive materials on our website. Thank you once again for purchasing Hyvox Bread Toaster, your Ingenious Home Collection.

Find more Hyvox Ingenious Home Collection products at

www.hyvox.com

Changing life concepts!

HYVOX[®]

Ingenious Home Collection
Changing life concepts!

Hyvox Inc.
100 City Centre Dr, RPO 2239,
Mississauga, Ontario
Canada L5B 3C7

info@hyvox.com
www.hyvox.com

'Hyvox' brand name and logo, 'Ingenious Home Collection' and 'Changing life concepts!' are registered trademarks of Hyvox Inc., Ontario, Canada.

Copyright © Hyvox Inc. 2005. E&OE.